# Keys

The following keys are provided with the vehicle.

1 Master keys
2 Valet key
3 Key number plate
4 Flat key

## When to use the master keys and valet key

- Use the master keys for normal daily use.
- For added security, lock the console box and the glove box with a master key and provide the parking attendant with the valet key.

## Key number plate

Keep the plate in a safe place such as your wallet, not in the vehicle. In the event that a key is lost, a new key can be made at your Lexus dealer using the key number plate.

## When riding in an aircraft

When bringing a master key onto an aircraft, make sure you do not press any buttons on the master key while inside the aircraft cabin. If you are carrying a master key in your bag etc., ensure that the buttons are not likely to be pressed accidentally. Pressing a button may cause the master key to emit radio waves that could interfere with the operation of the aircraft.

NOTICE

**To prevent key damage**

- Do not bend the keys, subject them to strong impact, expose them to high temperatures by placing them in direct sunlight, or get them wet.
- Do not expose the keys to electromagnetic materials or attach any material that blocks electromagnetic waves to the key surface.
- Do not disassemble the electronic key.